


Backstay flicker

– gives the mainsail space to move

The backstay flicker is a glass fibre rod fitted to the masthead on a fractional rigged boat. It lifts up a wire or rope backstay to allow for free passage of a full roach mainsail.



Complete kit with fasteners and instruction for assembly

Boat size	Art. No.
< 30 feet	511-120-01
30-37 feet	511-121-01

The backstay flicker comes complete with fasteners and backstay block.